

PLACCHE E GRIFFE

PFAFF


19-010 *taglia-cuci*

Placca
cod. 29-924993-62/000

Griffa
cod. 29-924993-70/053

per PFAFF
KL: 794 Hobbylock

19-012 *taglia-cuci*




per PFAFF
KL: 796 Hobbylock

cod. 29-924993-70/298


Griffa
cod. 29-924993-70/376
cod. 29-924993-70/377

19-014 *taglia-cuci*



per PFAFF
KL: 797, 799 Hobbylock


cod. 29-924993-70/506



cod. 29-924993-70/504

Griffa
cod. 29-924993-70/503

19-016 *taglia-cuci*




per PFAFF
KL: 783 Hobbylock

cod. 29-924993-70/633

Griffa
cod. 29-924993-70/631

19-018 *taglia-cuci*




per PFAFF
KL: 774 Hobbylock (1°)
776 Hobbylock (2°)

cod. 29-924993-70/776

Griffa
cod. 29-924993-71/013 (1°)
cod. 29-924993-70/797 (2°)
cod. 29-924993-70/975 (2°)

19-020 *taglia-cuci*



per PFAFF
KL: 787 Hobbylock (1°)
788 Hobbylock (2°)

cod. 29-924993-70/871

Griffa
cod. 29-924993-71/013 (1°)
cod. 29-924993-70/797 (2°)
cod. 29-924993-70/975 (2°)

19-022 *taglia-cuci*

Placca
cod. 29-924993-71/288

Griffa
cod. 29-924993-71/388
cod. 29-924993-71/395

per PFAFF
KL: 4860, 4870 Hobbylock

19-024 *taglia-cuci*

Placca
cod. 29-924993-71/289

Griffa
cod. 29-924993-71/388
cod. 29-924993-71/395

per PFAFF
KL: 4860, 4870 Hobbylock

19-026 *taglia-cuci*

Placca
cod. 29-924993-81/735

Griffa
cod. 29-924993-71/388
cod. 29-924993-71/395

per PFAFF
KL: 4862, 4872 Coverlock

19-028




per PFAFF
KL: 876, 894, 895, 905,
935, 955
899 Varimatic
907, 933 Hobbymatic
947, 953 Hobbymatic

cod. 93-032089-91

Griffa
cod. 93-036341-91

PFAFF

19-030



per PFAFF
KL: 1006, 1007, 1050, (1°)
1051, 1120, 1150, (1°)
1151, 6112, 6122, (1°)
6132, 6152, (1°)
1520, 1530 Select (1°)
1540 Select (1°)
6250, 6270, (2°)
2010, 2020 Tiptronic (2°)
1467 Creative (2°)
1471 Creative (2°)

cod. 93-038909-35
(= 98-694820-00)

Griffa
cod. 93-036341-91 (1°)
cod. 93-036344-91 (2°)

19-032 *zig zag*

Placca
cod. 93-038910-35

per PFAFF
KL: 2030, 2040 Tiptronic

Griffa
cod. 93-036344-91

19-034 *zig zag*

Placca
cod. 93-040086-35

per PFAFF
KL: 1212, 1222

Griffa
cod. 93-040343-05

19-036 *zig zag*

Placca
cod. 93-040087-35

per PFAFF
KL: 1197, 1209, 1214, 1215,
1217, 1222SE

Griffa
cod. 98-694850-00
(= 93-040360-05)

19-038 *zig zag*

Placca
cod. 93-040089-35

per PFAFF
KL: 1211, 1221

Griffa
cod. 93-040343-05

19-040 *zig zag*

Placca
cod. 93-040090-35

per PFAFF
KL: 1196, 1213, 1216

Griffa
cod. 98-694850-00
(= 93-040360-05)

19-042



per PFAFF
KL: 90, 92

cod. 93-101767-35

Griffa
cod. 93-835052-00

19-044




per PFAFF
KL: 80, 90, 92

cod. 93-102433-35

Griffa
cod. 93-835052-00

19-046



per PFAFF
KL: 8, 80

cod. 93-113590-00

Griffa
cod. 93-835050-00