


PLACCHE E GRIFFE

SINGER

25-086



cod. **356713**



cod. **179891**
(= 312679) (= 447581)

per SINGER
KL: serie 2600
serie 4800

25-088




cod. **356714**



cod. **179891**
(= 312679) (= 447581)

per SINGER
KL: serie 2600

25-090 zig zag



cod. **357193**

Griffa

cod.

per SINGER
KL: 6300 Pretaporté


25-092 taglia-cuci

Placca p. arrotolato
cod. **370218**

Griffe
cod. **370223**
cod. **370224**

per SINGER
KL: 14U-185

25-094 taglia-cuci



cod. **370278**
(= 370218)

Griffe
cod. **370223**
cod. **370224**

per SINGER
KL: 14U-185


25-096 ricamo

Placca
cod. **381134**

per SINGER
KL: 248, 262, 270C, 288,
588 Facility

25-098 catenella

Placca
cod. **381192**



cod. **445967**
(= 445090)

per SINGER
KL: 270C

25-100 catenella

Placca
cod. **381244**



cod. **506194/M**

per SINGER
KL: 2000 G23 Futura

Plastica
cod. **506194**

25-102 catenella

Placca
cod. **381365**



cod. **181843**

per SINGER
KL: 2001A13

Plastica
cod. **383334**

SINGER

25-104 imp. dritta

Placca
cod. **381372**



cod. **181843**

per SINGER
KL: 2001A13



Plastica
cod. **383334**

25-106 ricamo

Placca
cod. **381388**

per SINGER
KL: 2001A13

25-108 catenella

Placca
cod. **381416**



cod. **445802**

per SINGER
KL: 290

25-110 ricamo

Placca
cod. **381457**

per SINGER
KL: 2000 G23 Futura

25-112 imp. dritta

Placca
cod. **381486**




cod. **181843**

per SINGER
KL: 2010



Plastica
cod. **383334**

25-114 catenella



cod. **381488**



cod. **181843**

per SINGER
KL: 2010



Plastica
cod. **383334**

25-116 zig zag

Placca
cod. **382795**



cod. **506194/M**


per SINGER
KL: 1040G3



cod. **506194**

25-118 ricamo

Placca
cod. **383685**



cod. **181843**

per SINGER
KL: 1425



cod. **383334**