


PLACCHE E GRIFFE

SINGER

25-142



cod. **421410**



Metallo
cod. **506194/M**



Plastica
cod. **506194**

per SINGER
KL: 1050, 1100 Futura
6740, 6744, 6785, 6790


25-144 zig zag

Placca
cod. **422484**

Griffa
cod.

per SINGER
KL: 7186

25-146




cod. **423134**




cod. **179891**
(= 312679) (= 447581)

per SINGER
KL: serie 2100,
serie 2200 Strata


25-148



cod. **445883**
(= 44984-000)




cod. **446017 (1°)**
(= 103188) (= 103377)
(= 153286) (= 153797)
(= 155457) (= 172027)
(= 422406) (= 422407)



cod. **445967 (2°)**
(= 445090)

per SINGER
KL: 247, 248, 262, (1°)
288, 457, (1°)
588 Facility (1°)
270C (2°)

25-150



cod. **446027**
(= 37996) (= 44984-892)
(= 102468) (= 179608)
(= 310703) (= 352461)



cod. **446017**
(= 103188) (= 103377)
(= 153286) (= 153797)
(= 155457) (= 172027)
(= 422406) (= 422407)

per SINGER
KL: 162, 167, 168 Merrit
252, 257, 258, 259
327K, 337, 338, 348,
353, 354, 360, 362,
367, 368, 377, 378
410K, 416K, 477K, 478K
1247N3, 1263N
1280N3, 1288N3
2405N004, 6174
7101, 7108, 7174
8100, 8200

25-152 imp. dritta


Placca
cod. **446143**




per SINGER
KL: 2405N004, 1247N3
1263N3, 1280N3,
1288N3

cod. **446017**
(= 103188) (= 103377)
(= 153286) (= 153797)
(= 155457) (= 172027)
(= 422406) (= 422407)

25-154



cod. **447036**




cod. **447035**

per SINGER
KL: 1301

SINGER

25-156 imp. dritta

Placca
cod. **447143**




cod. **447035**

per SINGER
KL: 1301

25-158 zig zag

Placca
cod. **447573**



Griffa
cod. **447574**

per SINGER
KL: 7502, 7505, 9502,
9505, 9518

25-160



cod. **447580**



cod. **179891**
(= 312679) (= 447581)

per SINGER
KL: serie 1480, 1490
serie 2100,
serie 2200 Strata
serie 9500, 9600
serie 2100 Merrit

25-162 imp. dritta

Placca
cod. **503579**
(= 503578)

Griffa
cod. **179016**

per SINGER
KL: 414G

25-164 zig zag

Placca
cod. **503583**

Griffa
cod. **507042**

per SINGER
KL: 431


25-166 zig zag

Placca
cod. **503614**
(= 503592)



cod. **446017**
(= 103188) (= 103377)
(= 153286) (= 153797)
(= 155457) (= 172027)
(= 422406) (= 422407)

25-168



cod. **506229**
(= 174198)
(= 181842) (= 502398)




Metallo
cod. **506194/M**



Plastica
cod. **506194**

per SINGER
KL: 740, 744, 746,
760, 764, 766,
1000G3 Futura

25-170 catenella



cod. **506230**



Metallo
cod. **506194/M**



Plastica
cod. **506194**

per SINGER
KL: 740, 744, 746,
760, 764, 766,
1000G3 Futura
1050G3 Futura
1100G3 Futura