

**KI. DFB serie, DLR serie, DVK serie,
DWK serie, FX serie, MZ serie,
V serie, W serie, WXserie, RX serie**

**Crochet
*Loopers***

KI. DVK1700, DWK1800 serie



Crochet
Looper
cod. **19-7030-0**



Crochet (B)
Looper (B)
cod. **19-7120-0**



Crochet (C)
Looper (C)
cod. **19-7130-0**

KI. V7000, 7100 serie
W8000, 8100 serie



Crochet
Looper
cod. **19-8010-0**

KI. WX8700, 8800 serie



Crochet
Looper
cod. **19-5390-0**

KI. RX9700, 9800 serie
DX serie, MZ serie



Crochet
Looper
cod. **19-5250-0**

KI. DFB serie, FX serie



Crochet
Looper
cod. **19-4310-0**

KI. DFB serie



Crochet
Looper
cod. **19-1120-0**

KI. DFB serie



Spingitore
Spreader
cod. **19-4370-0**

KI. DLR serie



Crochet
Looper
cod. **19-5810-0**



Crochet
Looper
cod. **19-5820-0**



Crochet
Looper
cod. **19-5310-0**



Crochet
Looper
cod. **19-5350-0**



Crochet
Looper
cod. **19-5360-0**

KI. WX8800, RX9800



Spingitore
Spreader
cod. **19-5050-0**

KI. V7000, 7100 serie
W8000, 8100 serie



Spingitore
Spreader
cod. **19-8070-0**

KI. WX8700, 8800 serie



Salva ago
Needle guard
cod. **19-5400-0**

**KI. DVK serie, DWK serie,
V serie, W serie, WXserie, RX serie**

**Coltelli
*Knives***

KI. DVK 1700 serie



Coltello inferiore
Lower knife
cod. **07-7070-0**



Coltello sup. - destro
Upper knife - right
cod. **07-7030-0**



Coltello sup. - sinistro
Upper knife - left
cod. **07-7020-0**

KI. DVK 3200 serie



Coltello inferiore
Lower knife
cod. **07-2060-0**



Coltello sup. - destro
Upper knife - right
cod. **07-1240-0**



Coltello sup. - sinistro
Upper knife - left
cod. **07-4060-0**

KI. V7000, 7100 serie
W8000, 8100 serie



Coltello inferiore
Lower knife
cod. **07-1690-0**




Coltello superiore
Upper knife
cod. **07-1700-0**

KI. WX8700, 8800 serie



Coltello inferiore
Lower knife
cod. **07-5070-0**



Coltello superiore
Upper knife
cod. **07-5050-0**



Coltello inferiore
Lower knife
cod. **07-5580-0**



Coltello superiore
Upper knife
cod. **07-5700-0**

KI. RX9700, 9800 serie