

KL. 51100, 51200, 51300, 51400, 51500, 51700, 51800, 51900, 56100, 56200, 56300, 56400, 56500, 56700, 56800, 56900

KL. 51100, 56100BM



Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51108**

KL. 51100L, M, N



Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51108D**

KL. 51100R, S



Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51108E**

KL. 51200BM,
51300BG, BH, BJ, BL,
51500BL, 56300H



Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51208**

KL. 51200AA, AB

Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51208AA**

KL. 51200BW, BX



Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51208W**

KL. 51200AA, BY



Vite crochet
Looper screw
cod. 73

Vite salva crochet
Looper guard screw
cod. 73A

Salva crochet
Looper guard
cod. 51210Y

Crochet - Looper
cod. **51208Y**


KL. 56300V, Y, AV



Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51308**

KL. 51400BD, BE, BP, BT, BW,
56400P, T, W



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51408-12**



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51408-16**

KL. 51400BS, BU, BY

Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51408-32**

KL. 51200BK, BR,
51400BD, BE, BP, BT,
BW, BX, 51900BG,
56200K, 56400



Vite crochet
Looper screw
cod. 73

Crochet posteriore
Rear looper
cod. **51409**

KL. 51400BA, BB, BQ, BR,
BS, BU, BY



Vite crochet
Looper screw
cod. 73

Crochet posteriore
Rear looper
cod. **51409B**

KL. 51400, 56200L, 56300



Vite crochet
Looper screw
cod. 73

Crochet - Looper
cod. **51409C**

KL. 51500BJ, 56500J



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51508-16**
(= 51508M-16)

KL. 51500BJ, BM, BR, 56500J



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51508-18**
(= 51508M-18)

KL. 51700BJ, BK, BQ, BR, BU,
56700J



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51708**

KL. 51700BJ, BK, BQ, BR, BU,
56700J



Vite crochet
Looper screw
cod. 73

Crochet posteriore
Rear looper
cod. **51709**

KL. 51800BA, BB



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51808**

KL. 51800BA, BB



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51808A**

KL. 51800BA, BB



Vite crochet
Looper screw
cod. 73

Crochet posteriore
Rear looper
cod. **51809**

KL. 51900BH, BJ



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51908B-8**

KL. 51900BH, BJ



Vite crochet
Looper screw
cod. 73

Crochet anteriore
Front looper
cod. **51908B-9**


KL. 51200BL, 51300BM,
51500BJ, BM, BR, 51900BH, BJ,
56300M, 56500J, 56900H, J



Vite crochet
Looper screw
cod. 73

Crochet posteriore
Rear looper
cod. **51909C**
(= 51909B)

KL. 51900BH, BJ



Vite crochet
Looper screw
cod. 73

Crochet posteriore
Rear looper
cod. **51909D-9**