


Serie: LBH-781; LBH-782; LBH-783; LBH-784




B2709-771-000
Albero per leva



B2710-771-000
Molla



B2718-761-000
Molla




B2717-761-000
Base per molla




B2725-761-000
Molla



B2727-761-000
Molla



B2730-761-000
Perno leva fermacoltello




B2726-761-000-A
Molla



B2914-761-000
Molla




B2731-761-000
Ferma filo




B3404-771-000
Tirante



B3403-761-000
Tirante uncinato



B2602-771-000
Spina



B2619-232-000
Molla



B3115-761-000
Guida filo barra ago
SS-7110840-SP
Vite



B3118-771-000
Guida filo tensione
NS-6090310-SP
Dado




B3114-771-000
Guida filo
NS-6090310-SP
Dado



B1126-552-000
Guida filo
SS-7090710-SP
Vite



B3109-761-000
Passa filo
SS-7110710-SP
Vite



B1111-232-000
Guida filo
SS-7151210-SP
Vite

Serie: LBH-781; LBH-782; LBH-783; LBH-784




B3112-761-000
Molla tendifilo



B3126-012-000
Disco tensione



B3101-804-000
Molla tensione



119-56703
Bottone tensione
(rosso)

Serie: MBH-180; MEB-1890



DIM.	(mm)	COLTELLO
1/4"	(6.35)	B2701-180-F00
3/8"	(9.53)	B2701-180-K00
1/2"	(12.7)	B2701-180-L00
9/16"	(14.29)	B2701-180-V00
5/8"	(15.88)	B2701-180-M00
3/4"	(19.05)	B2701-180-N00
7/8"	(22.23)	B2701-180-P00
1"	(25.4)	B2701-180-Q00
1-1/8"	(28.57)	B2701-180-R00
1-1/4"	(31.75)	B2701-180-S00
1-3/8"	(34.9)	B2701-180-T00



B1109-180-000
Placca ago



B2523-180-000
Crochet



B2524-180-000
Crochet